
SERVER (8088)
IN
IN
JBOD
IN
OUT
OUT
JBOD
IN
OUT
OUT
JBOD
IN
OUT
OUT
JBOD
IN
OUT
OUT