RAID 5 Reset Instruction (Change RAID5 to RAID0 will destroy your old DATA, Please Backup before Proceed)

1) Turn on iT4UFER 4 bays unit and connect FW800 Cable
2) Copy this file to Mac Desktop, Double Click Configurator .dmg Icon

3) After double Configurator Icon, you will see setup window , Double Click Setup Icom

4) After Double click setup Icon, you will see the RAID Reset Menu

5) Make you check , RAID0, 4 disks & Enable Large Disks
After finished check The configuration , Click Confirure Icon to Save

6) After Click on Configure Icon , you will see this Screen , Click Exit

7) After Exit , Recycle T4 power , During Power Up , Select Set (Left Arrow Key (re-init) (Left) on the LCD Display, Wait for 10 Second

8) After Click Re-init , you will see this Screen , RAID5 4d, Click Set key Again (Left Arrow Key)

9) After Select RAID0 4d, you should see the Active Screen , Now RAID0 is Already Change.