

# Slide rails Installation Procedures

	<ol style="list-style-type: none"><li>1. Installation procedures for slide rails part number:<ol style="list-style-type: none"><li>a) 08-6022-XXX.</li><li>b) 08-6044-XXX.</li></ol></li><li>2. Slide rail kit components:<ol style="list-style-type: none"><li>a) Metal slide rail, three pieces.</li><li>b) Instructive manual.</li><li>c) Hardware kit.</li></ol></li></ol>
	<ol style="list-style-type: none"><li>3. Use 10-32 screws, kep nut, bar nut and 06-0330-01A chassis mountain bracket.</li></ol>
	<ol style="list-style-type: none"><li>4. Install chassis mountain bracket to flange mount stationary section. Do not tight screws completely to <b>kep nut</b>.</li></ol>



5. Install Flange mount stationary section, intermediate section must be inserted before end bracket is attached. If cabinet front area is not threaded, use **bar nut** inside cabinet to hold screws.



6. Install chassis mount bracket to the rear side of the cabinet. Adjust bracket accordingly to cabinet dimensions; tight slide rails-chassis mnt. bracket screws (box area).



7. Install slide rail chassis section to enclosure. Lock area must be on the chassis rear side.



8. Pull out intermediate section and proceed to mount chassis. Push lock for complete chassis insertion.



9. Complete inserted chassis.